

downloaded from digitalwatchlibrary.com

GUARANTEE & INSTRUCTIONS

GUARANTEE

We certify that the SEIKO watch described on the enclosed certificate of guarantee was manufactured by the SEIKO industrial group, and that it is guaranteed to be free from defects in material and workmanship for one year from date of purchase. Within that period, regulation, adjustment, repair or replacement of parts or movement will be performed without charge except in the case of damage caused by accidents or lack of care. To qualify for service under the guarantee, you must present your watch along with a valid guarantee certificate (see at end of this booklet) to the authorized SEIKO dealer from whom the watch was purchased or any member of the SEIKO Worldwide Service Network listed on pages 9 through 18 of this booklet. Postage, insurance, and shipping charges are to be paid by the owner of the watch.

THIS GUARANTEE IS IN LIEU OF ALL OTHER GUARANTEES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A

PARTICULAR PURPOSE OR OTHERWISE.

CHARACTERISTICS

 Frequency of crystal oscillator 32,768 Hz. (Hz. = Hertz-Cycle per second) 2. Accuracy Less than 10 seconds per month (at normal temperature) Continuous digital readout in hours, minutes and seconds using Field Effect Mode of liquid crystal U.C.C. 386 4. Battery (1 piece . . . Battery life is over one year.) 5. IC (Integrated circuit) C-MOS-LSI (Complementary Metal Oxide

2. TO SET THE MINUTE DIGITS

While the second digits are flashing, depress button "B", then the minute digits will immediately start flashing. This indicates that the minute digits are ready to be changed manually. Each depression of button "A" will then advance the minute digits one minute until the desired minute display is shown.

Circuit)

Silicon—Large Scale Integrated

3. TO SET THE HOUR DIGITS

While the minute digits are flashing, depress button "B" again, the hour digits will then start flashing. This now indicates that the hour digits are ready to be changed manually.

By depressing button "A", the hour digits are advanced one hour. Each depression of button "A" will then advance the hour digits one hour to the desired time.

Be sure to push the crown IN to the normal position each time after setting the time.

When you want to set only the minute or the hour, you can adjust it

independently from the other two timekeeping indicators.

For example, if you are travelling and need to adjust the hour, first pull the crown all the way OUT and then push button "B" two times. After the hour digits start flashing, depress button "A" each time you want to advance the hour digits one hour until the desired hour is reached.

THE CARE OF YOUR WATCH

The crystal oscillator in your watch is sealed in a vacuum capsule which is specially designed to protect against vibrations. Consequently, external conditions will have little effect on your watch in general use. However, remember that your watch contains a highly precise electronic circuit, and to maintain its high accuracy, you should not subject the watch to violent shocks or extreme temperatures.

BATTERY CHANGE

Although the miniature battery (U.C.C. 386) which powers your watch may last longer than one year, we recommend that it be replaced after each full year of use. Please contact an AUTHORIZED SEIKO DEALER for replacement.

REPAIR SERVICE

8

Please refer to the SEIKO Worldwide Service Network listed on the following page. The six Service Centers are available for repair service. However, for the convenience of those customers in areas other than the above, the Repair Reception Centers listed on pages 10-18 will be glad to receive and forward your watch for repair to one of our Service Centers.

PLEASE NOTE: Only the six Service Centers of the SEIKO Worldwide Service Network can repair or check a watch.

SEIKO DIGITAL QUARTZ LC (Liquid Crystal) Cal. 0624

Your quartz crystal digital display watch is a possession you can be proud of for its superb accuracy, design and features. The result of SEIKO's advanced micro miniaturization and micro electronic technologies. It is a product of K. Hattori & Co., Ltd. and its SEIKO industrial group.

The SEIKO Digital Quartz LC is a revolutionary electronic wrist watch with no moving parts. It incorporates a quartz crystal oscillator, an integrated circuit and a liquid crystal digital display to indicate the time in hours,

minutes and seconds.

The exceptional accuracy of your SEIKO Digital Quartz &C is the result of the highly stable oscillation of the quartz crystal, which is carefully cut to the most exacting specifications and aged to assure the most stable oscillations over a long period of time. Until SEIKO pioneered the development of the SEIKO Quartz wrist-sized watch, this degree of accuracy was available only in large quartz master clocks.

Now SEIKO Quartz watches are changing the world's standard of accuracy.

IMPORTANT


1. THIS GUARANTEE DOES NOT COVER THE WATCH BRACELET, STRAP, GLASS OR BATTERY.

2. THIS GUARANTEE IS VALID ONLY WHEN THE GUARANTEE CERTIFICATE AT END OF THIS BOOKLET IS PROPERLY FILLED IN BY THE AUTHORIZED SEIKO DEALER FROM WHOM THE WATCH WAS PURCHASED.

3. WE RESERVE THE RIGHT TO RELINQUISH ALL RESPONSIBILITY FOR REPAIRS IF THE WATCH IS TAMPERED WITH OR DAMAGED BY OTHER THAN SEIKO AUTHORIZED SERVICE FACILITIES.

> K. Hattori & Co., Ltd. Tokyo, Japan

HOW TO USE YOUR SEIKO DIGITAL QUARTZ LC Cal. 0624



HOW TO SET TIME

1. TO SET THE SECOND DIGITS

First, pull the crown all the way OUT to set the time. The second digits immediately start flashing when the crown is pulled all the way out. This indicates that the second digits are ready to be changed manually. When button "A" is then depressed, it automatically causes the second digits to return to "00" in accordance with a time signal.

Note: When the second digits indicate any numbers from "01" to "29", the digits are reset automatically whenever button "A" is depressed. When digits 30-59 are displayed and button "A" is depressed, one minute is added and the second digits immediately returns to "00" again.

Push the crown IN to the normal position after setting time. To make changes in the minute digits only, depress button "B" once after the crown is pulled all the way out.

The minute digits then start flashing and can be changed as described above.

HOW TO USE THE LIGHT

Button "A" serves both for setting the time and activating the tiny illuminating light. The light clearly illuminates the hour, minute and second digits in the dark.

When button "A" is depressed, the light is activated.

Button "A" activates the light only when the crown is at the normal position. Note: The battery life is over one year when the light button is pushed ten times a day (one second at one time). Unnecessary pushing of the light button may run the battery down in less than one year.

SEIKO Worldwide Service Network

(Repair Available)

U.S.A. Los Angeles

SEIKO Center

3321 Wilshire Blvd., Los Angeles, Calif. 90010

New York

SEIKO Center at Rockefeller Center

48 West 50th St., New York, N.Y. 10020

England

SEIKO Service Centre

Italy

1 Grangeway, London, NW6 2BN SEIKO Service Center

via Ippolito Nievo 37, Milan West Germany

SEIKO Service Center

4 Düsseldorf, Volmerswerther Str. 26

K. Hattori & Co., Ltd. Japan

5, Kyobashi 2-chome, Chuo-ku, Tokyo 104

SEIKO Worldwide Service Network

(Repair Reception)

Asia

Bahrain Ambassador Stores P.O. Box 237, Bahrain

A. Stephanides & Son, Ltd. Cyprus

P.O. Box 1878, 18, C-D Digenis Akritas Nicosia

Guam Hattori (Guam), Inc.

Suite 104, Guam International Trade Center,

(P.O. Box CV, Agana, Guam 96910)

Hong Kong SEIKO Service Center c/o Thong Sia Co., Ltd.

Star House, 3rd Floor, West Half, Salisbury Road, Kowloon

SEIKO Service Center

Shop Number 16, Shopping Arcade, Excelsior Hotel, Causeway Bay, Hong Kong

Republic of SEIKO Service Center

Gedung Pusat Perdagangan Pasar Baru,

Indonesia

Ground Floor No. 1-31 (Block A), Djakarta V

10

12

Saudi Arabia

Dammam

Hamad Al Abdul Rahman Al-Husayni P.O. Box 284, King Street, Dammam Jeddah Hamad Al-Abdul Rahman Al-Husayni

Shorbatly Bldg., Jeddah Riyadh

Hamad Al-Abdul Rahman Al-Husayni P.O. Box 498, King Abdul Aziz Street, Riyadh

SEIKO Service Center Republic of

c/o Thong Sia Co. (S) Pte. Ltd. Singapore 34, Bideford Road, Singapore 9 A.F. Debs

Syria P.O. Box 2396, Damascus

SEIKO Service Center Taiwan 7 Wuchang Street, 2nd Sec., Taipei

SEIKO Service Center Thailand

Republic of Vietnam

Australia Adelaide

SEIKO Service Centre (S.A.) Pty. Ltd. 12 Wyatt Street, Adelaide, South Australia, 5000

46-48, Rajdhamri Road, Bangkok

SEIKO Service Center

Oceania

115 Tu Do Street, Saigon

North America

Canada

Toronto, Ontario M3A 1B5

U.S.A. SEIKO Center

Chicago

Room 1112, 29 East Madison St., Chicago, Illinois 60602

SEIKO Center* Dallas

1708 Main St., Dallas, Texas 75201 SEIKO Center Honolulu

Shop No. 1132, Ala Moana Shopping Center, Honolulu, Hawaii 96814

In case of Mailing, send the watch directly to Los Angeles SEIKO Center.

SEIKO Center Suite 200, 109 Railside Road, Don Mills, Argentina

SEIKO Service Center Santa Fé 1441, Buenos Aires

Central & South America

SEIKO Service Center ·

SEIKO Service Center

Wahbe Tamari & Sons

P.O. Box 355, Amman

SEIKO Service Center

Suhail & Saud Bahwan

P.O. Box 169, Muscat

Suhail & Saud Bahwan

P.O. Box 114, Salalah

SEIKO Service Center

SEIKO Service Center

SEIKO Service Agency

Victoria, 3000

SEIKO Watch Service Shop

Tallerman (W.A.) Pty. Ltd.

491 Kent Street, Sydney

Thomson Street, Suva

*T.P.N.G. ... Territory of Papua and New Guinea

A.S. Farebrother & Co., Ltd.

Tallerman & Co. (N.Z.) Ltd.

Port Moresby Watchmakers

20 Fanshawe Street, Auckland

Room 103, Trinity Bldg.,

T.M. Kalaw St., Ermita, Manila

Tallerman & Co. (Q'land) Pty. Ltd.

or G.P.O. Box 310, Brisbane, 4001

165 Elizabeth Street, Brisbane, Queensland, 4000

Hub Arcade, 318-322 Little Collins St., Melbourne,

SEIKO Service Centre (Australia) Pty. Ltd.

G.P.O. Box 36, Dominion House 1st Floor,

P.O. Box 3665, 1st Floor, Warwick House,

P.O. Box 181, Port Moresby, T.P.N.G.

Box P-1231, G.P.O., 372 Newcastle Street, Perth, W.A.

or P.O. Box A370, Sydney South Post Office 2000, Sydney

Colon St. Cor. Legaspi St., Cebu City

WAKO

Ets. Soubra

Japan

Jordan

Kuwait

Lebanon

Malaysia

Muscat

Salalah

Sultanate of Oman

The Philippines

Brisbane

Melbourne

Perth

Sydney

New Zealand

T.P.N.G.*

73 Shah Avenue, Teheran

5, 4-chome, Ginza, Tokyo 104

Electronic Appliances Corporation

Fahed Al Salem Street, Kuwait

P.O. Box 2449, Saddoun Al Jassim Building,

Thong Sia Co. (S) Pte. Ltd., Kuala Lumpur Branch

45, Jalan Tuanku Abdul Rahman, Kuala Lumpur

P.O. Box 6959, 55 Tripoli Street, Beirut

Brasil Rio de Janeiro

Hase S/A, Imp. e Exp. Av. Rio Branco, 156-9: and. Salas 2434 e 2435, Rio de Janeiro

São Paulo **SEIKO Service Center** Rua Augusta, 2296, São Paulo

Colombia SEIKO Service Center Carrera 10a No. 14-20 Piso 7, Bogota

Ecuador Almacenes Eljuri Cia., Ltda.

P.O. Box Letra F, Cuenca

México Exactitud S.A.

S.L. Postosi No. 211-3er, Piso, México, 7, D.F. Perú Sasaki y Cia., S.A.

Av. Horacio Urteaga No. 1429,

Casilla No. 1297, Jesus Maria, Lima

14

Uruguay

Precision Ltda.

Soriano 1023, Montevideo Henrique Pfeffer, C.A. Venezuela

Apartado 6550, Edificio Centro Empresarial, Quinto Piso, Avenida Universidad,

(Traposos a Chorro), Caracas

Europe

Austria A. Weiner Ges.m.b.H.

Cumberlandstrasse 16, 1140 Wien

UTI S.A.B. Belgium Centre International Rogier,

13, Place Rogier, Brussels 1

Henning Arberg A.S. Denmark

France

Orholmvej 57, DK-2800, Lyngby UTI S.A.

139, Boulevard de Sébastopol, Paris 2^e

SEIKO Center 60 Avenue des Champs-Elysées, Paris 8^e Greece

Chronora S.A. 11, 3rd September St., Athens

Ireland

Denis Coakley & Co., Ltd. 39, Clarendon Street, Dublin 2 SEIKO Import-Hora B.V.

The Netherlands Norway

Groothandelsgebouw, E.2, Postbus 29118, Rotterdam Fabrikkenes Depot A/S Postboks 220, Tönsberg

Portugal

Lisboa

Poliprodutos

Representações e Comercio Geral, Lda. Av. Luis Bivar, Nº 93-A, Lisboa-1 Soc. de Rep.

Porto

Santos, Guimarães & Oliveira S.A.R.L. Rua de Fernandes Tomás, 316-Porto

Spain Barcelona

J.G. Girod, S.A. Consejo de Cient, 302, Barcelona

16

Madrid

J.G. Girod, S.A. Postas 17, Apartado 26, Madrid-12

Sweden

Ekman & Co. AB Stora Nygatan 29, Göteborg 1

Africa

South Africa

S.A. Watch Co. (Pty) Ltd. "Philadelphia Corner"

Jeppe & Von Wielligh Streets, Johannesburg

15

. 11

13

17

18